



Installation Steps:

1. Install jamb mullion and attach with fasteners as shown below.
2. Apply a compatible sealant to the (2) interior vertical seams and the (2) exterior vertical seams created between the frames and the jamb mullion. Leave a $\frac{1}{4}$ " sealant gap at the bottom on the exterior for weeping of jamb mullion.

