

## SERIES 3800-T

ANCHOR LOCATION WORKSHEET NAIL-ON FRAME

INSTALLER NOTE:

FRAME ANCHOR CHECKLIST	
FASTENER TYPE	
MINIMUM EMBEDMENT	
MINIMUM EDGE DISTANCE	
ANCHOR LOCATIONS	
FROM ENDS	
ON CENTER	

SILICONE SEALANT BEAD ON HEAD AND JAMBS ONLY. (BEHIND NAIL-FIN) INSTALLER NOTE: FLASHING PAPER INSTALLER NOTE: SIZE AND SPACING OF FASTENERS PER LOCAL CODE. (TYPICAL) (ON TOP OF NAIL-FIN) INSTALLER NOTE: (NOT BY FLEETWOOD) SEAL FASTENER HEADS INSTALLER NOTE: WITH COMPATIBLE SEALANT SOLID SHIMS AT ANCHOR AS SHOWN. (TYPICAL) LOCATIONS REQUIRED. (TYPICAL) (NOT BY FLEETWOOD) STUCCO FIXED WINDOW HEAD JAMBS SIMILAR **EXTERIOR** SCALE: 6" = 1' SILL PAN W APPLY CONTINUOUS BEAD OF SEALANT ALONG BACK AND SIDE LEGS. (BETWEEN SILL & SILL PAN ONLY) INSTALLER NOTE: SEAL FASTENER HEADS INSTALLER NOTE: WITH COMPATIBLE SEALANT SOLID SHIMS REQUIRED (TYPICAL) AS SHOWN. (TYPICAL) (NOT BY FLEETWOOD) INSTALLER NOTE: SET SILL PAN IN FULL

> FIXED WINDOW SILL SCALE: 6" = 1'

SILL DISCLAIMER: IT IS THE MANUFACTURERS DESIRE FOR THE INSTALLER TO NOT PIERCE THE SILL. IN SOME CASES THE CODE OR SPECIFICATIONS REQUIRE SUCH. IN THESE CASES THE INSTALLER IS RESPONSIBLE TO SEAL THESE BREACHES.

INSTALLER NOTE:

SIZE AND SPACING OF FASTENERS

PER LOCAL CODE. (TYPICAL) (NOT BY FLEETWOOD)

SHEET: 1 OF 1

**SIGNATURE** 

FLASHING PAPER (BEHIND NAIL-FIN AND SILL PAN)

BED OF SEALANT.

CAUTION: NO SEALANT BETWEEN

NAIL-FIN AND SILL PAN.

FRAME AND SILL PAN OR BETWEEN



## SERIES 3800-T

ANCHOR LOCATION WORKSHEET BLOCK FRAME

FRAME ANCHOR CHECKLIST	
FASTENER TYPE	
MINIMUM EMBEDMENT	
MINIMUM EDGE DISTANCE	
ANCHOR LOCATIONS	
FROM ENDS	

ON CENTER INSTALLER NOTE: SEAL FASTENER HEADS WITH COMPATIBLE SEALANT AS SHOWN. (TYPICAL) INSTALLER NOTE: SIZE AND SPACING OF FASTENERS PER LOCAL CODE. (TYPICAL) INSTALLER NOTE: CONTINUOUS SEALANT (NOT BY FLEETWOOD) W/BACKER ROD. (TYPICAL) INSTALLER NOTE: INSTALLER NOTE: FLASHING PAPER SOLID SHIMS AT ANCHOR (ON TOP OF STUCCO LOCATIONS REQUIRED. (TYPICAL) SURROUND) (NOT BY FLEETWOOD) STUCCO-STUCCO-SURROUND (OPTIONAL) رکا FIXED WINDOW HEAD **EXTERIOR** JAMBS SIMILAR SCALE: 6" = 1' APPLY CONTINUOUS BEAD OF SEALANT ALONG BACK AND SIDE LEGS. (BETWEEN SILL & SILL PAN ONLY) W SILL PAN INSTALLER NOTE: INSTALLER NOTE: CONTINUOUS SEALANT SOLID SHIMS REQUIRED (TYPICAL) W/BACKER ROD. (NOT BY FLEETWOOD) (TYPICAL) SET SILL PAN IN FULL BED OF SEALANT. INSTALLER NOTE: FLASHING PAPER (BEHIND CAUTION: NO SEALANT STUCCO SURROUND) BETWEEN FRAME AND SILL PAN. FIXED WINDOW SILL

SILL DISCLAIMER: IT IS THE MANUFACTURERS DESIRE FOR THE INSTALLER TO **NOT** PIERCE THE SILL. IN SOME CASES THE CODE OR SPECIFICATIONS REQUIRE SUCH. IN THESE CASES THE INSTALLER IS RESPONSIBLE TO SEAL THESE BREACHES.

DWG NO.: SERIES 3800-T ANCHOR LOCATION-BLOCK-(REVA)

SHEET: 1 OF 1

CUSTOMER SIGNATURE

SCALE: 6" = 1'

DATE: