

135° OUTSIDE CORNER WINDOW: NAIL-FIN FRAMES

330-T, 350-T, 450-T 3800-T & 4800-T

U:\Cadfiles_Admin\Products\Windows

CUSTOMER:



ORDER NO.:

SERIES:

ITEM NO.:

PLAN VIEW
SERIES 350-T SHOWN

ISOMETRIC VIEW
135° OUTSIDE CORNER STRUCTURE



*IMPORTANT: 450-T SHIM SPACE VARIES

INSTRUCTIONS: ENTER THE (3) RO (ROUGH OPENING) DIMENSIONS IN THE TABLE AND CALCULATE REQUIRED N.F.D. BELOW.
ENTER BUILDING EXTERIOR DIMENSIONS ONLY!

DIM. REF.	CUSTOMER ROUGH OPENING		FRAME ADD (A, B) AND SHIM DEDUCT (C)		FLEETWOOD NET FRAME DIMENSION
A		+	.1875*	=	
B		+	.1875*	=	
C		-	.50*	=	

CUSTOMER SIGNATURE:

DATE: