

## GREATER THAN 90° INSIDE CORNER WINDOW: NAIL-FIN FRAMES

330-T, 350-T, 450-T, 3800-T & 4800-T

U:\Cadfiles\_Admin\Products\Windows


CUSTOMER:

ORDER NO.:


SERIES:

ITEM NO.:

PLAN VIEW  
SERIES 350-T SHOWN



ISOMETRIC VIEW  
GREATER THAN 90°  
INSIDE CORNER STRUCTURE



†IMPORTANT: 450-T SHIM SPACE VARIES

CAUTION: INSTALLATION OF NAIL-FIN INSIDE CORNER WINDOWS REQUIRES FURRING AT JAMBS!!!

CUSTOMER TO FILL IN

**D** ANGLE: \_\_\_\_\_

**INSTRUCTIONS: ENTER THE (3) R.O. DIMENSIONS AND (1) ANGLE IN THE TABLES. ENTER BUILDING EXTERIOR DIMENSIONS ONLY!**

♦SEE FORMULA BELOW TO CALCULATE  
\*SERIES ADD

CUSTOMER TO FILL IN		FLEETWOOD TO FILL IN		
DIM. REF.	CUSTOMER R.O.	*SERIES ADD AND (C) SHIM DEDUCT	LONG POINT (INT.) N.F.D.	
<b>A</b>		+	*	=
<b>B</b>		+	*	=
<b>C</b>		-	.50 <sup>†</sup>	=

SERIES	**FRAME DEPTH
330-T	3.375
350-T	2.25
450-T <sup>†</sup>	3.00
3800-T	4.50
4800-T	5.75

➔ \*SERIES ADD = TAN[90-D/2](\*\*FRAME DEPTH-1)-(1/4" SHIM)

CUSTOMER SIGNATURE:

DATE: