

135° OUTSIDE CORNER WINDOW: NAIL-FIN FRAMES

330-T, 350-T, 450-T & 3800-T

U:\Cadfiles_Admin\Products\Windows (9/13/23)


CUSTOMER:

ORDER NO.:


SERIES:

ITEM NO.:

ISOMETRIC VIEW 135° OUTSIDE CORNER STRUCTURE



PLAN VIEW SERIES 350-T SHOWN



*NOTE: SERIES 450-T FRAME ADD/DEDUCTS
REQUIRES CUSTOM CALCULATIONS (SEE ENG.)

†IMPORTANT: 450-T SHIM SPACE VARIES PER WINDOW TYPE - (FIXED OUTSIDE GLAZED = .25"); (FIXED INSIDE GLAZED, P.O. w/BUTT HINGE, AND P.I. = .50"); (P.O. w/4-BAR HINGE = .625"). NOTE: 2X FOR DIM. REF. C

INSTRUCTIONS: ENTER THE (3) RO (ROUGH OPENING) DIMENSIONS IN
THE TABLE AND CALCULATE REQUIRED N.F.D. BELOW.
ENTER BUILDING EXTERIOR DIMENSIONS ONLY!

DIM. REF.	CUSTOMER ROUGH OPENING		FRAME ADD (A, B) AND SHIM DEDUCT (C)		FLEETWOOD NET FRAME DIMENSION
A		+	.125*	=	
B		+	.125*	=	
C		-	.50*	=	

CUSTOMER SIGNATURE:

DATE: